

WowWee

**Alive™**



**Lion Cub**  
**White Tiger Cub**



**User Manual**

Ages 3 +

Items No. 9007, 9008

**NOTE:** Make sure to set your Alive™ Cub to **Normal** Setting before playing. See the *Try Me and Normal Settings* section for more information.

## **Thank you for purchasing an Alive™ Cub from WowWee®!**

Your WowWee Alive™ Cub is a huggable and lifelike animal cub that wants you to adopt him and take him home! Give him love and attention and he comes “alive”! Pat his head or cradle him in your arms and he responds with blinking eyes, an animated mouth and cub sounds. He even purrs to let you know when he’s falling asleep!

Take a few minutes to look through this user manual so you can get to know your Cub!

## Package contents:

1 x WowWee Alive™ Cub

1 x User manual



Lion Cub  
Item no.: 9007




White Tiger Cub  
Item no.: 9008

### ***Take note of the following when playing with the Cub:***

- Avoid putting articles of clothing on him as it might inhibit the proper functioning of his sensors.
- Do not immerse the Cub or any parts of him in water or any other form of liquid.
- Do not drop, throw, or kick the Cub as this might damage his mechanical functions.
- If his fur becomes dirty, you can clean it using a clean cloth slightly dampened with warm water.
- Do not jam anything into his mouth or into his eyes.

## Alive™ Cub overview



## Battery details

This section outlines battery requirements and installation procedures.

The Cub will let you know when his batteries need changing. His movements will slow down and his audio level is always low, even if you try to adjust the volume.

### Battery requirements



The Alive™ Cub requires 4 x "AA" size alkaline batteries (included).

## Battery installation

**NOTE:** Make sure the main power switch is set to OFF prior to changing the batteries.

To install or change the Cub's batteries:


1. Locate and open the battery compartment door on the belly of the Cub by opening the flap of fur.
2. Use a Phillips screwdriver (not included) to remove the two screws on the battery compartment door.
3. Insert the 4 x "AA" batteries (included) according to the diagram. Ensure that the positive and negative polarities match the illustrations inside the battery compartment.
4. Replace the battery compartment door and replace the screws using the screwdriver. Do not over-tighten. Close the flap on the Cub's belly.



### Important battery information

- Use only fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, different types of batteries [standard (Carbon-zinc), Alkaline or rechargeable] or rechargeable batteries of different capacities.
- Remove rechargeable batteries from the toy before recharging them.
- Rechargeable batteries are only to be charged under adult supervision.
- Please respect the correct polarity, (+) and (-).
- Do not try to recharge non-rechargeable batteries.
- Do not throw batteries into the fire.
- Replace all batteries of the same type/brand at the same time.
- The supply terminals are not to be short-circuited.
- Remove exhausted batteries from the toy.
- Batteries should be replaced by adults.
- Remove batteries if the toy is not going to be played with for some time.
- This instruction manual should be kept as it contains important information.
- Batteries should be recycled or disposed of as per state and local guidelines.

# Try Me and Normal settings





## Try Me setting

When you first remove the Cub from his packaging, the switch will be set to **Try Me**. The **Try Me** function is used for demonstrating basic functions.

## Normal setting

When you want to play with him and access all his functions, you need to first set the switch to the **OFF** setting, and then wait 3 seconds before moving it to the normal position or setting it in the normal position.



**IMPORTANT:** When switching between **Try Me** and **Normal** power settings, you need to set the switch to **OFF** first, and then wait 3 seconds before changing the power setting. If you do not wait after switching the Cub to the **OFF** setting, he will remain in the previous power setting.

**NOTE:** In **Normal** power setting, the **Try Me** button becomes a button sensor located on his right ear. You can use this button to activate his cub behaviors, just as you would by scratching his head!

### Getting to know your Cub

Now that you've adopted your own WowWee Alive™ Cub, it's time to get to know him better.

#### Alive™ Cub's basic features

The Cub has a moving mouth and eyes that blink and respond. He also makes an array of baby animal sounds.

He is equipped with a touch sensor on his head. He also has a tilt sensor which can tell him when he's turned over or upright.




#### Powering ON/OFF the first time

The Cub's main power switch is located on his belly which you can access through the flap beneath in his fur. The switch has three settings: **Try Me**, **OFF**, and **Normal**.

**NOTE:** You will only need to access the main power switch when you first use him and/or when you change his batteries. After that, you can turn him on or off using his quick power switch (see the section *Powering ON/OFF in normal play*).

## Powering ON/OFF in normal play

The Cub's quick power button is located on his right ear. Once you set (rather than switch) the power switch to **Normal** setting, your Cub should automatically be in normal play mode when turned on. To turn him on after he powers down and enters **Sleep Mode**:



- Ensure the main power switch is set to **Normal**.  
Locate the quick power button and press it once.

**NOTE:** If you press it more than once after switching it to the **Normal** setting, you will be toggling the volume levels.

To turn him OFF:

- Hold quick power button down for about 10 seconds or set the power switch to OFF position.

## Volume control

You can adjust the volume to high or low on the Cub's right ear using the quick power switch to toggle the levels. To do so:

- Hold quick power button down for about 3 seconds.

## Sleep Mode

To conserve batteries, the Cub will go into **Sleep Mode** after about 5 minutes if you leave him unattended. He will close his eyes and purr for about 5 minutes in **Sleep Mode** if continued to be left unattended, after which he will power down to save batteries.

When you want to wake him from **Sleep Mode**, press the button on his right ear.

The Cub reacts like a real animal cub – he will make baby animal sounds, blink his eyes and move his mouth.

When you first turn him on, he will open his eyes  , open and close his mouth  , and then make a wake up sound. After that, he is ready to play with you!

Scratch or pet his head to see how he reacts. You can also quickly press his right ear for more reaction!



Turn him over on his back and he'll react. Turn him upright again to see what he does.

Be careful though – if you touch him or turn him over too many times, he might get annoyed and growl at you!

Spend some time to get to know your Cub by cuddling up with him and giving him affection!

**NOTE:** When you are done playing with him, make sure you turn him off by holding his right ear for about 10 seconds or set the power switch to OFF position.

## FAQs

**Q. My Cub seems to be moving and responding slower than normal... what's wrong?**

A. You probably need to change the batteries in the Cub. Refer to the **Battery details** section for information on battery requirements and installation.

**Q. My Cub speaks more quietly than normal... how do I fix that?**

A. Either you have the Cub's volume levels set at low (see the section **Volume control**), or you probably need to change the batteries in the Cub. Refer to the **Battery details** section for information on battery requirements and installation.

Note that when you turn him on his back, his volume level automatically lowers if it is set to high volume level. When you put him upright again, his volume level should return to high volume if he was already at high volume.

**Q. The Cub's facial animations have stopped and he just purrs... what's wrong?**

A. Your Cub is probably in **Sleep Mode**. To wake him from **Sleep Mode**, press his right ear.

**Q. The Cub seems to say only 4 different things... what's wrong?**

A. Your Cub is probably in **Try Me** power setting. See the section **Powering ON/OFF the first time** for how to set him in **Normal play** setting.

For more information on Alive™ Cubs, go to

<https://wowweealiveonline.com> <--please give me the update website

If you have any questions that are not answered in this manual, refer to

<https://support.wowwee.com/hc/en-us>

To see the full range of WowWee products, go to

<https://wowwee.com>

Register at <https://registerwowwee.com>



# Lion Cub White Tiger Cub

Manufactured and distributed by © 2017 WowWee Group Limited. Product names, designations, and logos are trademarks or registered trademarks of WowWee Group Limited. All rights reserved.

Customer Service Website: <https://support.wowwee.com/hc/en-us>

We recommend that you retain our address for future reference.

Product and colors may vary.

Packaging printed in China.

WARNING! This product is not suitable for children under 3 years because of small parts - choking hazard.

CAN ICES-3 (B)/NMB-3(B)

MADE IN CHINA

#### CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### NOTE

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or experienced radio/TV technician for help

This Device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

For full list of inputs, please visit

<http://wowwee.com/alivecubs>

For warranty information, please visit

<http://wowwee.com/information/warranty>

**WARNING!** This equipment may experience difficulty and/or memory loss when subjected to any electrostatic discharge, radio frequency interference, or sudden power surge/interruption. The user is encouraged to reset the equipment should any of these occur.



WowWee Group Limited  
Energy Plaza, 301A-C  
92 Granville Road  
T.S.T. East, Hong Kong

WowWee Canada Inc.  
3700 Saint Patrick Street  
Suite 206  
Montreal, QC, H4E 1A2, Canada



9007US05TOP\_JML